

DOMED ALUMINIUM HOOP FRAME
(H) 1.88M X (W) 1.2M X (L) 2.4M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

3	SMALL ROUND ALUMINIUM HOOP
6	ALUMINIUM TUBE 1.5M
9	ALUMINIUM TUBE 1.2M
4	JOINER TEE
2	JOINER CROSS
4	UPRIGHT TUBE CLIP

ASSEMBLY PROCESS BASE

STEP 1: Take 7 of the 1.2m tubes and lay them out in two squares side by side sharing the center pole. Insert the joiners (tees) into the four corners, and two crosses in the centre.

STEP 2: Insert the three hoops on each intersection of the frame.

STEP 3: Insert the three hoops on each intersection of the frame and push into the ground 300mm to get a 1.2m erected height.

STEP 4: Use the upright tube clips in both ends of the last 2x 1.2m poles to create support bars which connects all the hoops together.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

This does not come with a door, you just need to remove a few clips and pegs to gain entrance from any side you wish.

