

# HEAVY-DUTY LOW CAGE (H) 1.2 X (W) 1.5M X (L) 5M

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

## CONTENTS

2	19MM X 2M ALUMINIUM TUBE
16	19MM X 1.5M ALUMINIUM TUBE
4	LARGE JOINER CORNER
4	LARGE JOINER TEE

## IF ORDERED WITH COVER

1	COVER
28	STEEL PEGS
30	19MM CLIPS

## ASSEMBLY PROCESS

**Step 1:** Use 8 of the 1.5m tubes as the legs and push them into the joiners. Please refer to the cage diagram for help.

**Step 2:** Use 4 of the 1.5m tubes as the width bars.

**Step 3:** Connect the remaining 1.5m + 1.5m + 2m tube with 2 tee joiners between them to create the 5m length bars.

**Step 4:** Push the legs of the cage into the ground to the correct erected height. Please refer to the height table for more information.

**Step 5:** Lay cover (if ordered) over the frame and secure using the 19mm clips and spacing them equally over the crossbars and legs. Bury the ends of the cover and secure with pegs.

**Please Note:** If due heavy forecast of snow, please remove the netting beforehand.

HEIGHT TABLE		
ERECTED HEIGHT	UPRIGHT HEIGHT	PUSH INTO SOIL
1.5M	1.854M	354MM
1.2M	1.5M	300MM
900MM	1.2M	300MM
700MM	900MM	200MM
500MM	600MM	100MM

