

# LARGE HIGH TOP ALUMINIUM HOOP FRAME

(H) 1.8M X (W) 1.2M X (L) 3M

## CONTENTS

3	LARGE HIGHTOP ALUMINIUM HOOP
6	ALUMINIUM HOOP EXTENSION 800MM
6	ALUMINIUM TUBE 1.5M
3	ALUMINIUM TUBE 1.2M
4	JOINER CORNER
2	JOINER TEE
4	UPRIGHT TUBE CLIP

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

## ASSEMBLY PROCESS BASE

**STEP 1:** Take 2 of the 1.2m tubes and 2 of the 1.5m tubes and lay them on the ground into a rectangle, repeat this twice to create two small rectangles connecting to each other. Connect each corner with a joiner corner, and center pole with joiner tees.

**STEP 2:** Insert the 800mm extension poles into the upright slots of the corners and tees.

**STEP 3:** Insert the hoop width ways into the top of the uprights, repeat this three times.

**STEP 4:** To create the support bar use the last 1.5m tubes and insert the upright tube clips at either end. Once created, place this in the center of the hoops, once between each hoop.

For a tight fit some pressure is required when fitting the clips, and joiners into the aluminium.

