

SMALL ALUMINIUM HOOP FRAME

(H) 1.46M X (W) 1.2M X (L) 1.5M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

2	SMALL ROUND ALUMINIUM HOOP
4	ALUMINIUM HOOP EXTENSION 800MM
3	ALUMINIUM TUBE 1.5M
2	ALUMINIUM TUBE 1.2M
4	JOINER CORNER
2	UPRIGHT TUBE CLIP

ASSEMBLY PROCESS

STEP 1: Take two of the 1.5m poles and lay them on the ground, then lay two of the 1.2m poles either side to create a rectangle.

STEP 2: Place the four corners on each corner making sure the joiner has a free slot pointing upwards.

STEP 3: Insert the four the 800mm hoop extensions into the free slots in the joiner corners. Then insert the round hoops into the extensions, this will complete either end.

STEP 4: To assemble the cloche support bar insert the upright tube clips into either end of the last 1.5m tube. Once assembled fixed lengthways between the two hoops. Space equally apart.

This does not come with a door, you just need to remove a few clips and pegs to gain entrance from any side you wish.

