

SMALL HIGH TOP ALUMINIUM HOOP FRAME

(H) 1.56M X (W) 0.9M X (L) 4.5M

CONTENTS

4	SMALL HIGHTOP ALUMINIUM HOOP
8	ALUMINIUM HOOP EXTENSION 800MM
9	ALUMINIUM TUBE 1.5M
4	ALUMINIUM TUBE 0.9M
4	JOINER CORNER
4	JOINER TEE
6	UPRIGHT TUBE CLIP

ASSEMBLY PROCESS

STEP 1: Take 2 of the 0.9m tubes and 2 of the 1.5m tubes and lay them on the ground into a rectangle, repeat this three times to create two three rectangles connecting to each other. Connect each corner with a joiner corner, and center poles with joiner tees.

STEP 2: Insert the 800mm extension poles into the upright slots of the corners and tees.

STEP 3: Insert the hoop width ways into the top of the uprights, repeat this four times.

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

