

RAISED POND FRAME COVER (H) 350MM (W) 1.2M X (L) 1.2M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

8	19MM X 1.2M ALUMINIUM TUBE
4	19MM X 345MM ALUMINIUM TUBE
8	LARGE JOINER CORNER
1	CABLE TIES (PACK OF 100)
1	COVER

ASSEMBLY PROCESS

Step 1: Lay the 4x 1.2m tubes out on the floor in a square.

Step 2: Insert 4x joiner corner into the ends of the poles creating a fixed square.

Step 3: Insert 4x 345mm tubes into the spare ports on the joiner corner to add the legs.

Step 4: Repeat steps 1 & 2 to create a second square and place this on top of the legs with the spare ports of the joiner corner facing downwards, this will create a solid structure.

Step 5: Lay the netting over the frame evenly and use the cable ties provided to secure the netting to the frame.

Please Note: If due a heavy forecast of snow please remove the frame from the pond.

