

# POND FRAME COVER

## (W) 1.2M X (L) 2M

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

### CONTENTS

2	19MM X 2M ALUMINIUM TUBE
2	19MM X 1.2M ALUMINIUM TUBE
4	LARGE JOINER DOOR CORNER
1	COVER
24	19MM CLIPS

### ASSEMBLY PROCESS

**Step 1:** Space 2x1.2m tubes on the ground 2m apart.

**Step 2:** Place the remaining 2x2m tubes horizontally between the existing tubes to create a rectangle.

**Step 3:** Insert the large joiner door corners into the ends of the tubes creating a firm rectangle.

**Step 4:** Lay the netting cover over the frame and pull taut. Use the 19mm clips to clamp the netting to the framework fixing it in place.

**Please Note:** If due a heavy forecast of snow please remove the frame from the pond.

