

POND FRAME COVER

(W) 1.5M X (L) 2M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

2	19MM X 2M ALUMINIUM TUBE
2	19MM X 1.5M ALUMINIUM TUBE
4	LARGE JOINER DOOR CORNER
1	COVER
30	19MM CLIPS

ASSEMBLY PROCESS

Step 1: Space 2x1.5m tubes on the ground 2m apart.

Step 2: Place the remaining 2x2m tubes horizontally between the existing tubes to create a rectangle.

Step 3: Insert the large joiner door corners into the ends of the tubes creating a firm rectangle.

Step 4: Lay the netting cover over the frame and pull taut. Use the 19mm clips to clamp the netting to the framework fixing it in place.

Please Note: If due a heavy forecast of snow please remove the frame from the pond.

