

PORTABLE DOMED CAGE

(W) 1.2M X (L) 1.2M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

2	SMALL ROUND ALUMINIUM HOOP
5	ALUMINIUM TUBE 19MM X 1.2M
2	LARGE JOINER 19MM DOOR UPRIGHT TUBE CLIP
4	LARGE JOINER (CORNER)

ASSEMBLY PROCESS BASE

STEP 1: Take 4 of the 1.2m poles and lay them out in a square.

STEP 2: Connect the 4 joiners at all corners.

STEP 3: Place the hoops on top of the joiners and push in.

ASSEMBLY PROCESS CLOCHE SUPPORT BAR

STEP 1: Insert 2 x joiner upright tube clip to 1 x 19mm x 1.2m.

STEP 2: Clip 1x support bar in between the two hoops.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

