

PORTABLE DOMED CAGE

(W) 1.2M X (L) 1.2M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

2	SMALL ROUND ALUMINIUM HOOP
5	ALUMINIUM TUBE 19MM X 1.2M
2	LARGE JOINER 19MM DOOR UPRIGHT TUBE CLIP
4	LARGE JOINER (CORNER)

1	COVER
9	CROP COVER CLIPS
12	U PINS

ASSEMBLY PROCESS BASE

STEP 1: Take 4 of the 1.2m poles and lay them out in a square.

STEP 2: Connect the 4 joiners at all corners.

STEP 3: Place the hoops on top of the joiners and push in.

ASSEMBLY PROCESS CLOCHE SUPPORT BAR

STEP 1: Insert 2 x joiner upright tube clip to 1 x 19mm x 1.2m.

STEP 2: Clip 1x support bar in between the two hoops.

STEP 3: To attach the cover, lay over the top of the hoops leaving an equal overhang at both ends. Use the crop cover clips provided to clip onto the fabric (1 every half a metre) and then insert a u-pin through the eyelet and push into the soil. The crop cover clips allow you to secure the fabric without having to pierce it with a steel peg. We don't provide clips when covering with fleece or polythene because the clips can tear the fabric.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

Please note: If due heavy forecast of snow please remove cover before hand.

