

PORTABLE DOMED CAGE

(W) 1.2M X (L) 4.5M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

4	SMALL ROUND ALUMINIUM HOOP
9	ALUMINIUM TUBE 19MM X 1.5M
2	ALUMINIUM TUBE 19MM X 1.2M
6	LARGE JOINER 19MM DOOR UPRIGHT TUBE CLIP
4	LARGE JOINER (CORNER)
4	LARGE JOINER (FLAT TEE)

1	COVER
24	BLACK HOOP CLIPS 19MM
26	U PINS

ASSEMBLY PROCESS BASE

STEP 1: Take 6 of the 19mm x 1.5m poles and lay them in 2 rows of 3, and place a 1.2m poles at either end to create a long rectangle.

STEP 2: Connect the 6 joiners(4 corners and 4 tees).

STEP 3: Place the hoops on top of the joiners and push in.

STEP 3: Use pipe clips provided to secure your netting to the tubing.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

Please note: If due heavy forecast of snow please remove cover before hand.

ASSEMBLY PROCESS CLOCHE SUPPORT BAR

STEP 1: Insert 6 x joiner upright tube clip into 3 x 1.2m poles. This creates the support bars.

STEP 2: Clip 1x support bar in between each hoop.

