

# PORTABLE DOMED CAGE

## (W) 1.2M X (L) 6M

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

### CONTENTS

5	SMALL ROUND ALUMINIUM HOOP
12	ALUMINIUM TUBE 19MM X 1.5M
2	ALUMINIUM TUBE 19MM X 1.2M
8	LARGE JOINER 19MM DOOR UPRIGHT TUBE CLIP
4	LARGE JOINER (CORNER)
6	LARGE JOINER (FLAT TEE)

### ASSEMBLY PROCESS BASE

**STEP 1:** Take 8 of the 19mm x 1.5m poles and lay them in 2 rows of 4, and place a 1.2m pole at either end to create a long rectangle.

**STEP 2:** Connect the 10 joiners( 4 corners and 6 tees).

**STEP 3:** Place the hoops on top of the joiners and push in.

### ASSEMBLY PROCESS CLOCHE SUPPORT BAR

**STEP 1:** Insert 8 x joiner upright tube clip into 4 x 1.2m poles. This creates the support bars.

**STEP 2:** Clip 1x support bar in between each hoop.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

