

# PORTABLE HIGHTOP CAGE

## (W) 0.8M X (L) 4.5M

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

### CONTENTS

4	SMALL HIGHTOP ALUMINIUM HOOP
9	ALUMINIUM TUBE 19MM X 1.5M
2	ALUMINIUM TUBE 19MM X 800MM
6	LARGE JOINER 19MM DOOR UPRIGHT TUBE CLIP
4	LARGE JOINER (CORNER)
4	LARGE JOINER (FLAT TEE)

### ASSEMBLY PROCESS BASE

**STEP 1:** Take 6x 1.5m length bars, and 2x 800mm width bars and lay them out into rectangle, refer to diagram.

**STEP 2:** Connect the 4 joiner corners on the 4 corners, and 4 tees in the middle.

**STEP 3:** Place the hoops on top of the joiners and push in.

**STEP 2:** Clip 1x support bar in between each hoop.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

Please note: If due heavy forecast of snow please remove cover before hand.

### ASSEMBLY PROCESS CLOCHE SUPPORT BAR

**STEP 1:** Insert 6x joiner upright tube clips to the remaining 1.5m tubes at both ends.

