

PORTABLE SQUARE CAGE

(W) 1.2M X (L) 3M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

3	SQUARE ALUMINIUM HOOP
8	ALUMINIUM TUBE 19MM X 1.5M
2	ALUMINIUM TUBE 19MM X 1.2M
8	LARGE JOINER 19MM DOOR UPRIGHT TUBE CLIP
4	LARGE JOINER (CORNER)
2	LARGE JOINER (FLAT TEE)

1	COVER
16	BLACK HOOP CLIPS 19MM
18	U PINS

ASSEMBLY PROCESS BASE

STEP 1: Take 4 of the 1.5m length bars and 2 x 1.2m width bars and lay them out into a rectangle.

STEP 2: Connect the 4 joiner corners on the corners, and 2 tees in the middle.

STEP 3: Place the hoops on top of the joiners and push in.

STEP 3: Use pipe clips provided to secure your netting to the tubing.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

Please note: If due heavy forecast of snow please remove cover before hand.

ASSEMBLY PROCESS CLOCHE SUPPORT BAR

STEP 1: Insert 8x joiner upright tube clips to the remaining 1.5m tubes at both ends.

STEP 2: Clip 2x support bars in between each hoop.

