

DOMED ALUMINIUM HOOP FRAME

(H) 1.88M X (W) 1.2M X (L) 3M

CONTENTS

3	SMALL ROUND ALUMINIUM HOOP
12	ALUMINIUM TUBE 1.5M
3	ALUMINIUM TUBE 1.2M
4	JOINER TEE
2	JOINER CROSS
4	UPRIGHT TUBE CLIP

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

ASSEMBLY PROCESS BASE

STEP 1: Make two rectangles side by side sharing the center pole. Using the 1.5m poles for the length, and 1.2m poles for the width. Insert the joiners (tees) into the four corners, and two crosses in the centre.

STEP 2: Insert the three hoops on each intersection of the frame.

STEP 3: Insert the 6 x 1.5m poles into the bottom of the joiners to create the 6 legs. Push the legs into the soil 300mm.

STEP 4: Use the upright tube clips in both ends of the last 2x 1.5m poles to create support bars which connects all the hoops together.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

This does not come with a door, you just need to remove a few clips and pegs to gain entrance from any side you wish.

