

HEAVY-DUTY LOW CAGE (H) 1.5 X (W) 1.2M X (L) 3M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

6	19MM X 1.854M ALUMINIUM TUBE
4	19MM X 1.5M ALUMINIUM TUBE
3	19MM X 1.2M ALUMINIUM TUBE
4	LARGE JOINER CORNER
2	LARGE JOINER TEE

IF ORDERED WITH COVER

1	COVER
16	STEEL PEGS
16	19MM CLIPS

HEIGHT TABLE		
ERECTED HEIGHT	UPRIGHT HEIGHT	PUSH INTO SOIL
1.5M	1.854M	354MM
1.2M	1.5M	300MM
900MM	1.2M	300MM
700MM	900MM	200MM
500MM	600MM	100MM

ASSEMBLY PROCESS

Step 1: Use the 1.854m tubes as the legs and push them into the joiners. Please refer to the cage diagram for help.

Step 2: Use the 1.2m tubes as the width bars.

Step 3: Connect the 1.5m + 1.5m tube with 1 tee joiner between them to create the 3m length bars.

Step 4: Push the legs of the cage into the ground to the correct erected height. Please refer to the height table for more information.

Step 5: Lay cover (if ordered) over the frame and secure using the 19mm clips and spacing them equally over the crossbars and legs. Bury the ends of the cover and secure with pegs.

Please Note: If due heavy forecast of snow, please remove the netting beforehand.

