

HEAVY-DUTY LOW CAGE

(H) 1.5 X (W) 1.5M X (L) 4M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

| | |
|---|------------------------------|
| 4 | 19MM X 2M ALUMINIUM TUBE |
| 6 | 19MM X 1.854M ALUMINIUM TUBE |
| 3 | 19MM X 1.5M ALUMINIUM TUBE |
| 4 | LARGE JOINER CORNER |
| 2 | LARGE JOINER TEE |

IF ORDERED WITH COVER

| | |
|----|------------|
| 1 | COVER |
| 24 | STEEL PEGS |
| 24 | 19MM CLIPS |

| HEIGHT TABLE | | |
|----------------|----------------|----------------|
| ERECTED HEIGHT | UPRIGHT HEIGHT | PUSH INTO SOIL |
| 1.5M | 1.854M | 354MM |
| 1.2M | 1.5M | 300MM |
| 900MM | 1.2M | 300MM |
| 700MM | 900MM | 200MM |
| 500MM | 600MM | 100MM |

ASSEMBLY PROCESS

Step 1: Use the 1.854m tubes as the legs and push them into the joiners. Please refer to the cage diagram for help.

Step 2: Use the 1.5m tubes as the width bars.

Step 3: Connect the 2m + 2m tube with 1 tee joiner between them to create the 4m length bars.

Step 4: Push the legs of the cage into the ground to the correct erected height. Please refer to the height table for more information.

Step 5: Lay cover (if ordered) over the frame and secure using the 19mm clips and spacing them equally over the crossbars and legs. Bury the ends of the cover and secure with pegs.

Please Note: If due heavy forecast of snow, please remove the netting beforehand.

