

HIGHTOP ALUMINIUM HOOP FRAME

(H) 1.68M X (W) 0.8M X (L) 3.6M

CONTENTS

4	SMALL HIGHTOP ALUMINIUM HOOP
17	ALUMINIUM TUBE 1.2M
4	ALUMINIUM TUBE 800MM
4	JOINER TEE
4	JOINER CROSS
6	UPRIGHT TUBE CLIP

ASSEMBLY PROCESS BASE

STEP 1: On a flat surface take 2x 1.2m length tubes and 2x 800mm width tubes to create a rectangle, repeat this three times to create three interconnecting rectangles. Connect the four corners with the joiner tees, and four cross joiners in the middle.

STEP 2: Insert a hoop onto each end of the frame and two in the middle making sure the joiners are fully submerged.

STEP 3: Connect the upright tube clips into each end of 3x 1.2m tubes to create the support bars, you can then connect these between the hoops.

STEP 4: (This part may require two people)
Mark on the floor where the legs of the cage are going

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

