

HIGHTOP ALUMINIUM HOOP FRAME

(H) 1.68M X (W) 0.8M X (L) 6M

CONTENTS

5	SMALL HIGHTOP ALUMINIUM HOOP
12	ALUMINIUM TUBE 1.5M
10	ALUMINIUM TUBE 1.2M
5	ALUMINIUM TUBE 800MM
4	JOINER TEE
6	JOINER CROSS
8	UPRIGHT TUBE CLIP

ASSEMBLY PROCESS BASE

STEP 1: Take 2x 800mm width tubes and 2x 1.5m length tubes and create a rectangle. Repeat this four times to create four interconnecting rectangles on a flat surface. Connect each corner with a tee joiner and six crosses in the middle.

STEP 2: Insert a hoop onto each end of the frame and two in the middle making sure the joiners are fully submerged.

STEP 3: Connect the upright tube clips into each end of 8x 1.5m tubes to create the support bars, you can then connect these between the hoops.

STEP 4: (This part may require two people)
Mark on the floor where the legs of the cage are going

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

