

SMALL HIGH TOP ALUMINIUM HOOP FRAME

(H) 1.56M X (W) 0.9M X (L) 1.5M

CONTENTS

| | |
|----------|---------------------------------------|
| 2 | SMALL HIGHTOP ALUMINIUM HOOP |
| 4 | ALUMINIUM HOOP EXTENSION 800MM |
| 3 | ALUMINIUM TUBE 1.5M |
| 2 | ALUMINIUM TUBE 900MM |
| 4 | JOINER CORNER |
| 2 | UPRIGHT TUBE CLIP |

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

| | |
|-----------|------------------------------|
| 1 | COVER |
| 16 | BLACK HOOP CLIPS 19MM |
| 16 | U PINS |

ASSEMBLY PROCESS

STEP 1: Take 2 of the 0.9m tubes and 2 of the 1.5m tubes and lay them on the ground into a rectangle, connect each corner with a joiner to complete the rectangle.

STEP 2: Insert the 800mm extension poles into the upright slots of the corners.

STEP 3: Insert the hoop width ways into the top of the uprights, repeat this at both ends.

STEP 4: To create the support bar use the last 1.5m tube and insert the upright tube clips at either end. Once created, place this in the center of the hoops, one between each hoop.

STEP 5: Place the cover over the top of the cage leaving equal netting down either side. Pull the netting taught and use the steel pegs to peg into the soil. Use the pipe clips provided to fasten the netting to the tubing.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

Please note: If due heavy forecast of snow please remove cover before hand.

This does not come with a door, you just need to remove a few clips and pegs to gain entrance from any side you wish.

