

# SMALL HIGH TOP ALUMINIUM HOOP FRAME

## (H) 1.56M X (W) 0.9M X (L) 3M

### CONTENTS

<b>3</b>	<b>SMALL HIGHTOP ALUMINIUM HOOP</b>
<b>6</b>	<b>ALUMINIUM HOOP EXTENSION 800MM</b>
<b>6</b>	<b>ALUMINIUM TUBE 1.5M</b>
<b>3</b>	<b>ALUMINIUM TUBE 0.9M</b>
<b>4</b>	<b>JOINER CORNER</b>
<b>2</b>	<b>JOINER TEE</b>
<b>4</b>	<b>UPRIGHT TUBE CLIP</b>

### ASSEMBLY PROCESS

**STEP 1:** Take 2 of the 0.9m tubes and 2 of the 1.5m tubes and lay them on the ground into a rectangle, repeat this twice to create two small rectangles connecting to each other. Connect each corner with a joiner corner, and center pole with joiner tees.

**STEP 2:** Insert the 800mm extension poles into the upright slots of the corners and tees.

**STEP 3:** Insert the hoop width ways into the top of the uprights, repeat this three times.

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

